		Name	9	
1.	Remove engines from create			
	Install exhaust, air filter housing and ac	dd oil		
	Remove spark plug and check compres	ssion with gauge		
	Set choke to OFF, set throttle to 1/2			
	Pull the engine over with 4 quick pulls	and recorded your read	ling	psi.
2.	install the test fuel tank and test run er	ngine		
		Pass	Fail	symptoms
	Be sure it runs with the choke off			
	Check low speed idle			
	Check high speed idle			
	Verify that it holds a steady speed with	n no surging or rough ru	nning	
3.	Remove valve cover and set engine to check valve lash with Feeler Gauge, hat Clearance should be .004-006 intake at	ve instructor verify you	r findings	
		Clearance (before)	Clearance	(after, if adjuster)
	Intake valve lash			
	Exhaust valve lash			
	Recheck compression if you adjusted t	he valves		
	Pull the engine over with 4-5 quick pul	ls and recorded your re	ading	psi.
	Drain oil back into the quart of oil you	got it from		

4.	Begin disassembly					
	Air filter housing					
	muffler					
	Remove carburetor and throttle assemble					
	Remove cylinder head					
	Remove valves from head					
	Measure valve stem diameter					
	Intake valve stem					
	Exhaust valve stem					
	Measure valve guide diameter					
	Intake guide diameter					
	Exhaust guide diameter					
	Calculate valve stem to guide clearan	ce				
	Intake guide dia.	Exhaust guide dia				
	Minus	Minus				
	Intake stem dia.	Exhaust stem dia				
	Equals clearance	Clearance				
Have th	ne instructor check your work					

Re-install the valve cover onto cylinder head

1.	Measure the bore and stroke of this engine
	Calculate displacement
	Bore2 x stroke x .7854 x number of cylinders
	To convert, CID/61.02 = liters
	Bore
	Stroke
	Displacement in cubic inches
2.	Remove any small items bolted to the block.
3.	Measure crank shaft end play with the dial indicator
	record your reading inches
4.	Remove flywheel; use an impact gun to get the nut off. Have instructor help with removing flywheel from crankshaft
5.	Remove engine cover, DO NOT DAMAGE THE GASKET! Have the instructor help if needed.
	Remove the low oil sensor
	Remove connecting rod cap and remove piston.
	Remove crankshaft from block

6.	Measure crankshaft		
	Rod journal		
	Main bearing journal, flywheel side _		
	Main bearing journal, output side		_
7.	Measure oil clearance of the rod on t	he crank	
	Plastigage reading		
8.	Remove wrist pin and measure Pin hole in piston		
	Pin hole in connecting rod		
	Measure wrist pin dia		
Ca	lculate clearances		
	Piston to pin		
	Rod to pin		
9.	Measure camshaft intake		exhaust
	Heel to Nose	Heel to Nose	
	Base circle	Base circle	

Lobe lift	Lobe lift		_
Measure cylinder bore with T-gau more at 90 degrees.	ge in 3 places top to	bottom on the thru	ist surface then 3
Тор	Top		
Middle	Middl	e	
Bottom	Botto	m	
11. Measure piston Skirt ½ inch abov	e the bottom of skir	t	_
12. Calculate piston to cylinder wall cl	learance	Minus	nsurement nrement
13. Reassemble the bottom end. Have	e your instruct inspe	ect the cam timing be	efore you install the
cover. 14. Install the cylinder head and adjus	st the valves.		
15. With the valve cover removed and	d the engine set to 1		C)
check valve lash with Feeler Gauge, ha Clearance should be .004-006 intake a	_	-	
siearance snould be .004-000 intake a	Clearance	31	
Intake valve lash			
Exhaust valve lash		_	
 Install the carburetor, muffler and engine. 	d other external cor	nponents test fuel ta	ank and test run
17. The magneto must be set to .009-	.012 clearance. Hav	e you instructor assi	st and inspect
	Pass	Fail	symptoms
Be sure it runs with the choke off			

	Check low speed idle
	Check high speed idle
	Verify that it holds a steady speed with no surging or rough running
Write d	lown the Torque specs for the bolts
	6mm
	8mm
	10mm

Student Name	Pre-Alignment Inspection	Tie Rod Replacement, Outer	Tie Rod Replacement, Inner	Ball Joint, Replace Press-In	Ball Joint, Replace Bolt-In	Wheel Bearing, Replace Bolt-In	Wheel Bearing, Replace Press-In	Wheel Bearing, Repack	Wheel Bearing, Adjust	McPhearson Strut Replacement	Shocks/Damped Replacement	Leaf Spring/Shackle Replace	Bushing Replacement, Press-In	Dismount and Mount Tires	Balance and Road Force	TPMS Reset	Steering Rack Replacement	Steering Rack Adjustment	Steering Box Replacement	Steering Box Adjustment	Pitman Arm Replacement	Clock Spring Replacement	U Joint	Perform Four Wheel Alignment	Power Steering Pump, Replace	Power Steering Line, Replace	Power Steering Pressure Test	Sway Bar Bushing/end link
																												\square
																												\vdash

AUTO227

Task List	Fluid inspection, dip stick	Fluid inspection, w/o dipstick	Fluid flush, pan drop w/filter	Fluid flush, machine	Fluid leak	replace park nuetral switch	Stall test	Lock up test	diag trans related issue	pressure test	NVH diag, mounts	NVH, non mount issue	Diag incorrect gear ratio/power flo	Diag electrical fault	Shift cable adjustment	scan tool work sheet		R&R transmission RWD	R&R transmission, FWD	complete trans teardown rebuild
Student Name																				

Nam	e	
AUTO	D228	Main Journal Dia. Spec
Cranl	kshaft Measurements	Rod Journal Dia. Spec
		Out-of-Round
INSTI	RUCTION:	Crank shaft end play
1.	Measure crank shaft end	play.
2. NOT	Remove the crankshaft. SUSE A PLYBAR OR SCREWDE	See instructor for instructions on how to remove the main caps. DO RIVER!
3. meas	Make measurements of surements to determine wea	the Main and Rod journals at one point then at 90deg. from first ar and out-of-round.
4.	Measure crankshaft run-	out with a dial indicator.
End p	olay measurement	In spec_YES / NO
MAIN	N JOURNALS Diameter	
First	Measurement	Second Measurement 90deg from first
1		
2		
3		
4		
5		
6		
7		

ROD JOURNALS		
1		
2		
3		
4		
5		
6		
7		
8		
Measure crankshaft run out with dial inc	dicator	

Measure Cylin	nder Bore:		
Cylinder bore	specification		
Cylinder Tape	r specification		
Out of round s	specification		
Piston skirt me	easurement		
Skirt to cylinde	er wall clearance		
Cylinder #1	Тор		90 degrees
	Middle		90 degrees
Bottom		90 degrees	
Taper		In spec YES	S / NO
Out of Round		In spec YES	S / NO
Largest bore n	measurement		In spec YES / NO
Piston skirt me	easurement		In spec YES / NO
Skirt to cylinde	er wall clearance		In spec YES / NO
Cylinder #2	Top		90 degrees
	Middle		90 degrees
Bottom		90 degrees	
Taper		In spec YES	S / NO
Out of Round		In spec YES	S / NO
Largest bore r	neasurement		In spec YES / NO
Piston skirt me	easurement		In spec YES / NO
Skirt to cylinde	er wall clearance		In spec YES / NO
Cylinder #3	Тор		90 degrees
	Middle		90 degrees
Bottom		90 degrees	
Taper		In spec YES	S / NO
Out of Round		In spec YES	S / NO
Largest bore n	neasurement		In spec YES / NO

Piston skirt me	easurement		In spec YES / NO					
Skirt to cylind	er wall clearance		In spec YES / NO					
Cylinder #4	Top	90) degrees					
Cylinder #4	•							
	Middle	90) degrees					
Bottom		90 degrees						
Taper		In spec YES / NO						
Out of Round		In spec YES / NO						
Largest bore r	neasurement		In spec YES / NO					
Piston skirt m	easurement		In spec YES / NO					
Skirt to cylinde	er wall clearance		In spec YES / NO					

Valve and Valve Guide Measurements and Cylinder head inspection

OI LOO.	intako		
1.	Valve Guide Specs New	Service Limit_	
2.	Valve Stem Specs New	_ Service Limit_	
3.	Valve Stem-to-Guide Clearance Nev	V	_Limit
4.	Valve margin New	Service limit	
5.	Valve face angle	Valve seat angle_	
SPECS:	Exhaust		
1.	Valve Guide Specs New	Service Limit_	
2.	Valve Stem Specs New	_ Service Limit_	
3.	Valve Stem-to-Guide Clearance Nev	V	_Limit
4.	Valve margin New	Service limit	
5.	Valve face angle	_Vlave seat angle	9
Cylinde	er head flatness		

OBJECTIVES:

SPECS: Intake

- 1. To identify the intake and exhaust valves and combustion chamber type.
- 2. Check cylinder head for flatness.
- 3. To disassemble the cylinder head using the appropriate valve spring compressor.
- 4. To measure the valve guide using the small hole gauge or Sunnex clearance gauge
- 5. To measure the valve stem using the micrometer.
- 6. To calculate the valve stem to guide clearance.

INSTRUCTIONS/STEPS:

- 1. Look up the needed Specs and write them in the space provide below.
- 2. Measure the valve and guide and calculate the clearance.
- 3. Have your Instructor check your work.

Cylinder head flatness	
First Valve Set	
Intake Valve Guide Top	Intake Valve Stem Top
Middle	Middle
Bottom	Bottom
The largest measurement from the Guide	In Spec YES / NO
Minus	
The smallest measurement from the Stem	In Spec YES / NO
This Is your Valve-to-Guide Clearance	In Spec YES / NO
Exhaust valve Guide TopI	Exhaust Stem Valve Top
Middle	Middle
Bottom	Bottom
The largest measurement from the Guide	In Spec YES / NO
Minus	
The smallest measurement from the valve Stem	In Spec YES / NO
This Is your Valve-to-Guide Clearance	In Spec YES /NO

Second Valve Set

Intake Valve Guide Top	_ Intake Valve Stem Top
Middle	Middle
Bottom	Bottom
The largest measurement from the Guide	In Spec YES / NO
Minus	
The smallest measurement from the Stem	In Spec YES / NO
This Is your Valve-to-Guide Clearance	In Spec YES / NO
Exhaust valve Guide Top	Exhaust Stem Valve Top
Middle	Middle
Bottom	Bottom
The largest measurement from the Guide	In Spec YES / NO
Minus	
The smallest measurement from the valve Stem	In Spec YES / NO
This Is your Valve-to-Guide Clearance	In Spec YES /NO

Third Valve Set

Intake Valve Guide Top	_ Intake Valve Stem Top
Middle	Middle
Bottom	Bottom
The largest measurement from the Guide	In Spec YES / NO
Minus	
The smallest measurement from the Stem	In Spec YES / NO
This Is your Valve-to-Guide Clearance	In Spec YES / NO
Exhaust valve Guide Top E	Exhaust Stem Valve Top
Middle	Middle
Bottom	Bottom
The largest measurement from the Guide	In Spec YES / NO
Minus	
The smallest measurement from the valve Stem	In Spec YES / NO
This Is your Valve-to-Guide Clearance	In Spec YES /NO

Fourth Valve Set

Intake Valve Guide Top	_ Intake Valve Stem Top
Middle	Middle
Bottom	Bottom
The largest measurement from the Guide	In Spec YES / NO
Minus	
The smallest measurement from the Stem	In Spec YES / NO
This Is your Valve-to-Guide Clearance	In Spec YES / NO
Exhaust valve Guide Top E	Exhaust Stem Valve Top
Middle	Middle
Bottom	Bottom
The largest measurement from the Guide	In Spec YES / NO
Minus	
The smallest measurement from the valve Stem	In Spec YES / NO
This Is your Valve-to-Guide Clearance	In Spec YES /NO

Bottom end reassembly 1
Plastigage Work Sheet
Objective: To determine the oil clearance of the main bearings.
Torque Spec, Main Bearing Caps
Oil Clearance Spec
Crank Endplay Spec
Clean the crank, blocks and bearings. Install the crank and place one strip of plastigage on each of the main journal. Torque the main bearing cap to spec in the order given by the service manual.
DO NOT SPIN THE CRANK.
Remove the caps and read the thickness of the plastigage with supplied scale (the wrapper).
Write the measurements down.
1
2
3
4
5
6
7
Are the clearances within spec?
Have the instructor go over the reading with you.
Remove the plastigage with your fingernail, oil the crank, install the caps and torque to spec. The crank should spin easily by hand, with your figure tips. If not, see the instructor.
Using a dial indicator
Measure crankshaft endplay endplay spec

Bottom end reassembly 2

Objective: To install pistons and rods and to measure oil clearance and end play of the

Torque Spec, connec	ting rod bolt/nut	
Connecting rod side/ ax	kial clearance spec	
Connectino	g rod oil clearance	
Before installing pistons have the inst	ructor demonstrate the installation pr	ocess
If there are studs on the connecting roand crank.	od place rubber protectors on them to	protect the cylinder wall
Install one piston at a time.		
Once the piston is in the cylinder, che	ck that there are no scratches on the	cylinder wall.
The piston should move smoothly wit Plastigage the rod bearings		
1	5	_
2	6	
3	7	_
4	8	
Oil the bearing and torque to spec		

Oil the bearing and torque to spec.

Measure the connecting rod side / axial clearance.

Rotate the crank two to three revolutions. The crank should turn freely with no noises. Have the instructor check your work.

Install the next piston and rod.

Using a Feeler gauge or dial indicator Connecting rod side/ axial clearance Is the endplay on the rods is in spec?

1	YES /NO	5	_YES /NO
2	YES /NO	6	_YES /NO
3	YES /NO	7	_YES /NO
4	YES /NO	8	_YES /NO